




"T" HS0105




"A" HS0107




"S" HS0102




"T" HS0106




"G" HS0111



"T" HS0103




"T" HD0001




Manovelle
Crank handles

COD.	A
HB0008	296
HB0009	361
HB0010	396 STANDARD




HS0243




Aste di trasmissione
Cross shafts

COD.	Z
HA0018	1370
HA0017	1470
HA0019	1520
HA0020	1640
HA0021	1900



Supp. per controventatura
Supportings for bracing

HC0039



Solo per Tecno200.../F400...
Only For Tecno 200.../F400...

Prolunghe manovella
Crank handle exstensions

HS0151

HA0014

Per F400.../F500...
For F400.../F500...

Per Tecno200.../T600...
For Tecno 200.../T600...

